EDAC Connector

(307-030-500-202)

Flexible Strap

Connector Assembly

Assembly PCB ("dummy")

Threaded Metal Insert → **Screw**

Washer

EDAC Connector → **O-Ring Gasket**

Sealant

Plexiglass Cover →

Assembly Procedure:

1. Connect the cables from a connector assembly to their respective straws.

2. Step 1 can be performed with the CDC horizontal or vertical.

3. Feed the straps through the plexigalss cover holes corresponding to the connector positions.

4. Slide the plexiglass cover towards the endplate.

5. Secure connectors to the plexiglass cover with screws, O-ring gaskets and washers.

6. Rotate CDC vertical and seal around connectors with non-silicone sealant.

Title				
CDC Electronics Assembly				
Size	Number		Revision	
A				
Date:	8/12/2008		Sheet **2** of	**2**
File:	C:\Program Files\..\CDC_Assembly2.SchDoc	Drawn By:	**F.J. Barbosa**	